

8-18-2023 REV.A



7929 Lincoln Ave. Riverside, CA 92504 Phone: 951.689.ICON | Fax: 951.689.1016

PART #	DESCRIPTION
51015	22-23 TUNDRA/23 SEQUOIA 6" COILOVER SPACER KIT

COMPONENTS INCLUDED			
(2) 154037 6" TUNDRA COILOVER SPACER			
HARDWARE INCLUDED			
(8) 605830 M10-1.25 SERRATED FLANGE NUT GR8.8 CZINC	605969 VIBRATITE RED 2ML BULLET		
TOOLS REQUIRED			
RATCHET EXTENSIONS TORQUE WRENCH	14MM SOCKET / WRENCH 24MM SOCKET / WRENCH		
TECH NOTES			
	· · · · · · · · · · · · · · · · · · ·		

1. ADVERTISED LIFT HEIGHT RANGES ARE FOR A STOCK EQUIPPED VEHICLE. INCREASING WEIGHT



WARNING!

- ** READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!
- ** ICON VEHICLE DYNAMICS RECOMMENDS THAT YOU EXERCISE EXTREME CAUTION WHEN WORKING UNDER A VEHICLE THAT IS SUPPORTED WITH JACK STANDS.
- ** ICON VEHICLE DYNAMICS RECOMMENDS ALL INSTALLATION TO BE PERFORMED BY A PROFESSIONAL SHOP/SERVICE TECHNICIAN. PRODUCT FAILURE CAUSED BY IMPROPER INSTALLATION WILL NOT BE COVERED UNDER ICON'S WARRANTY POLICY.

INSTALLATION

2. NOT COMPATIBLE WITH TRD PRO.

1. In continuation of the main instructions (51010).

OF VEHICLE DUE TO ACCESSORIES WILL ALTER LIFT RANGE.

3. NOT COMPATIBLE WITH AVS EQUIPPED TRUCKS.

- 2. Place the coilover spacer on top of the OEM coilover, the bolt pattern is designed so the spacer will only fit one way.
- 3. Use the OEM nuts and red threadlocker to secure the spacer onto the coilover and torque the nuts to 35 ft-lbs using a 14mm.
- 4. Place the assembly into the coilbucket, aligning the studs into place. Use the supplied nuts and red threadlocker and torque to 35 ft-lbs using a 14mm.
- 5. Insert the lower eyelet into the lower control arm and torque the OEM bolts to 130 ft-lbs.
- 6. Refer back to the main instructions (51010) to continue install.

VERIFY ALL FASTENERS ARE PROPERLY TORQUED BEFORE DRIVING VEHICLE.

RETORQUE ALL NUTS, BOLTS AND LUGS AFTER 100 MILES AND PERIODICALLY THEREAFTER.

ICON VEHICLE DYNAMICS LIMITED LIFETIME WARRANTY

ICON Vehicle Dynamics warrants to the original retail purchaser who owns the vehicle on which the product was originally installed. ICON Vehicle Dynamics does not warrant the product for finish, alterations, modifications and/or installation contrary to ICON Vehicle Dynamics instructions. ICON Vehicle Dynamics products are not designed, nor are they intended to be installed on vehicles used in race applications, for racing purposes or for similar activities. (A "race" is defined as any contest between two or more vehicles, or a contest of one or more vehicles against the clock, whether or not such contest is for a prize). This warranty does not include coverage for police or taxi vehicles, race vehicles, or vehicles used for government or commercial purposes. Also excluded from this warranty are sales outside of the United States of America and Canada.

ICON Vehicle Dynamics' obligation under this warranty is limited to the repair or replacement, at ICON Vehicle Dynamics' discretion, of the defective product. Any and all costs of removal, installation or re-installation, freight charges and incidental or consequential damages are expressly excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered.

ICON Vehicle Dynamics components must be installed as a complete kit as shown in our current application guide. Any substitutions or exemptions of required components will immediately void the warranty. Some finish damage may happen to parts during shipping and is not covered under warranty.

This warranty is expressly in lieu of all other warranties expressed or implied. This warranty shall not apply to any product that has been improperly installed, modified or customized subject to accident, negligence, abuse or misuse.



7929 Lincoln Ave. Riverside, CA 92504 Phone: 951.689.ICON Fax: 951.689.1016 www.iconvehicledynamics.com



