



JK TAILGATE VENT COVER & LICENSE PLATE RELOCATION MOUNT

DOCUMENT: INST_25240_REVA • UPDATED: NOV 2020

Thank you for purchasing this ICON Vehicle Dynamics product. Please read through this entire document before proceeding with installation. If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation. Check your packages immediately upon arrival to ensure that everything listed is included, and to check for damage during shipping. If anything is missing or damaged, or if you need technical assistance with any aspect of this installation, call (951) 689-ICON as soon as possible.



APPLICATION

These installation instructions apply to the following products:

25240 07/18 JK REAR DOOR VENT COVER

COMPONENTS INCLUDED

- (1) JK Tailgate Plate
- (1) JK Vent Cover

TECH NOTES

NOTE: These installation instructions are based on a clean installation on to a stock 2007-18 Jeep JK Wrangler. Previously modified vehicles may require additional steps.

TOOLS REQUIRED

- 13mm Socket & Ratchet

INSTALLATION INSTRUCTIONS

1. Ensure the vehicle is placed on a flat, level surface with the transmission in PARK, the tires chocked, and the emergency brake ON. Wear safety glasses from this point forward.
2. If present, remove the spare tire, OE spare tire mount and third brake light. Use a 13mm socket and ratchet to remove the eight (8) M8- 1.25 X 30mm bolts to remove the tire carrier.
3. Install the JK Tailgate Vent Plate. It will fit around the Jeep's tailgate vent. Orient it so that the "ICON" logo is at the bottom, and not reversed.

IMPORTANT NOTICES - PLEASE READ FIRST

- ✓ **READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!**
- ✓ **ICON VEHICLE DYNAMICS RECOMMENDS ALL INSTALLATION TO BE PERFORMED BY A PROFESSIONAL SHOP/SERVICE TECHNICIAN. PRODUCT FAILURE CAUSED BY IMPROPER INSTALLATION WILL NOT BE COVERED UNDER ICON'S WARRANTY POLICY.**

Use four (4) of the M8- 1.25 X 30mm OE tire carrier bolts in the bolt locations along the left and right edges of the Vent Plate. Snug these bolts but do not fully tighten them yet.

4. **OPTIONAL:** if you are relocating the license plate to the tailgate, install it on to the JK Vent Cover. Be sure to orient it so the vent holes in the cover are below the license plate. License plate mounting holes are already cut into the Vent Cover, but hardware to attach the license plate is not included. Note that a license plate and/or third brake light may be required in your area.
5. Install the JK Vent Cover. Orient it so the vent holes are at the bottom as shown in the product photo at the top of this page. Use the remaining four (4) M8- 1.25 X 30mm OE tire carrier bolts in the top and bottom bolt locations.
6. Use the 13mm socket and ratchet to tighten the eight (8) bolts.

Congratulations! Your installation is complete.



LIMITED LIFETIME WARRANTY

ICON Vehicle Dynamics warrants to the original retail purchaser who owns the vehicle on which the product was originally installed. ICON Vehicle Dynamics does not warrant the product for finish, alterations, modifications and/or installation contrary to ICON Vehicle Dynamics instructions. ICON Vehicle Dynamics products are not designed, nor are they intended to be installed on vehicles used in race applications, for racing purposes or for similar activities. (A "race" is defined as any contest between two or more vehicles, or a contest of one or more vehicles against the clock, whether or not such contest is for a prize). This warranty does not include coverage for police or taxi vehicles, race vehicles, or vehicles used for government or commercial purposes. Also excluded from this warranty are sales outside of the United States of America and Canada.

ICON Vehicle Dynamics' obligation under this warranty is limited to the repair or replacement, at ICON Vehicle Dynamics' discretion, of the defective product. Any and all costs of removal, installation or re-installation, freight charges and incidental or consequential damages are expressly excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered.

ICON Vehicle Dynamics components must be installed as a complete kit as shown in our current application guide. Any substitutions or exemptions of required components will immediately void the warranty. Some finish damage may happen to parts during shipping and is not covered under warranty.

This warranty is expressly in lieu of all other warranties expressed or implied. This warranty shall not apply to any product that has been improperly installed, modified or customized subject to accident, negligence, abuse or misuse.



ICON VEHICLE DYNAMICS®
PERFORMANCE SUSPENSION SYSTEMS AND SHOCK ABSORBERS

7929 Lincoln Ave. Riverside, CA 92504
Phone: 951.689.ICON Fax: 951.689.1016
www.iconvehicledynamics.com



FOLLOW US ON FACEBOOK!

