



7929 Lincoln Ave. Riverside, CA 92504
 Phone: 951.689.ICON Fax: 951.689.1016

Instruction Sheet:

PART# IVD2110 / IVD2110B	2006-Current RAM 1500 4WD Leveling Kit
---------------------------------	---

Enclosed Parts List
(2) Coilover Spacers
Hardware Included
(6) M10 x 1.25 Flange Nuts

Vehicle Applications
2006-2013 RAM 1500 4WD

Installation Notes
** Installation by a certified mechanic is highly recommended. **
** ICON Vehicle Dynamics is not responsible for any damage or failure resulting from improper installation. **
** WARNING! ICON Vehicle Dynamics recommends that you exercise extreme caution when working under a vehicle that is supported with jack stands. **

**** READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION, AND TIRE DAMAGE MAY RESULT TO THE VEHICLE! ****

BEGIN INSTALLATION

- 1. ENSURE TRUCK IS IN GEAR OR IN PARK, SET PARKING BRAKE, TURN OFF ENGINE AND CHOCK TIRES!**
- 2.** With the vehicle sitting on level ground, measure from the center of the front wheel hub to the top of the fender opening. Record this measurement; you will refer to it later to determine total lift height.
- 3.** Using a heavy duty jack, raise up the front of the truck and support with jack stands under the frame rail.
- 4.** Remove wheels and tires.
- 5.** Remove sway bar end link nut located on lower control arm.
- 6.** Loosen and remove lower coilover nut, but do not remove bolt at this time.
- 7.** Loosen the upper balljoint nut on the spindle, but do not remove.
- 8.** Strike the spindle carefully to cause the upper balljoint to break loose.
- 9.** Remove the upper coilover mounting nuts.
- 10.** With the use of a pry bar, pull down on the upper control to release tension and remove the upper balljoint nut.

11. Remove the lower coilover mounting bolt completely.
12. Mark the orientation of the front and rear lower control arm alignment cams and then loosen them enough to move the arm.
13. Push down on the suspension components while lifting the fork of the OE coilover over the mount on the lower control arm.
14. Remove the OE coilover from the vehicle, and install the IVD Leveling Suspension spacer on top of the coilover using the factory hardware.
15. Reinstall the OE coilover assembly and spacer back onto the vehicle, making sure to clock the orientation of the assembly 180 degrees from how it was originally installed. Use the provided hardware to mount the assembly in the coil bucket.
16. Perform Steps 14-5 in reverse order to complete one side.
17. Perform Steps 5-15 on the opposite side.
18. Install wheels and tires, torque lugs to factory specs.
19. Once installation is complete, roll truck back and forth to allow suspension to settle. Test drive vehicle re-check the torque of all fasteners and re-torque wheels on vehicle after first 100 miles of use. Failure to perform the post inspection checks may result in vehicle component damage and/or personal injury or death to driver and/or passengers.
20. It is recommended that you have your vehicle professionally aligned whenever lift components are installed. A certified alignment technician with lifted vehicle experience is highly recommended. Adjust headlights whenever vehicle has been lifted or lowered for proper orientation.

**** Installer is responsible for ensuring vehicle safety and handling ability after performing modifications to suspension. ****

**ICON Vehicle Dynamics
LIMITED LIFETIME WARRANTY**

ICON Vehicle Dynamics warrants to the original retail purchaser who owns the vehicle on which the product was originally installed. ICON Vehicle Dynamics does not warrant the product for finish, alterations, modifications and/or installation contrary to ICON Vehicle Dynamics instructions. ICON Vehicle Dynamics products are not designed, nor are they intended to be installed on vehicles used in race applications, for racing purposes or for similar activities. A "race" is defined as any contest between two or more vehicles, or a contest of one or more vehicles against the clock, whether or not such contest is for a prize. This warranty does not include coverage for police or taxi vehicles, race vehicles, or vehicles used for government or commercial purposes. Also excluded from this warranty are sales outside of the United States of America and Canada.

ICON Vehicle Dynamics' obligation under this warranty is limited to the repair or replacement, at ICON Vehicle Dynamics' discretion, of the defective product. Any and all costs of removal, installation or re-installation, freight charges and incidental or consequential damages are expressly excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered. ICON Vehicle Dynamics components must be installed as a complete kit as shown in our current application guide. Any substitutions or exemptions of required components will immediately void the warranty. Some finish damage may happen to parts during shipping and is not covered under warranty. This warranty is expressly in lieu of all other warranties expressed or implied. This warranty shall not apply to any product that has been improperly installed, modified or customized subject to accident, negligence, abuse or misuse.

ICON Vehicle Dynamics
7929 Lincoln Ave. Riverside, CA 92504 Phone: 951.689.ICON Fax: 951.689.1016
www.iconvehicledynamics.com